Perrett Communications

Time & Date Change on BT Versatility Telephone System.

This must be done from a BT Versatility V8 Systemphone (Normally Extn 20)

Setting the time and date

To set the time and date on the system

• From the Programming Extension, press the PROGRAMME Key
• Press the Scroll Down Key until ‘System programming’ is displayed
• Select ‘System programming’.
• Enter the System Programming Password (1111) and select ‘System’.
• Select ‘Time and date’.
• Enter the correct time in 24-hour format, (e.g. 2pm as 1400). The 'Display' will prompt for a date.
• If you only wish to set the time select ‘Confirm’ and the 'Display' will revert to the Idle Menu.
• Enter the date in dd/mm/yy format, (e.g. 10 December 1999 as 101299). When the date has been entered the 'Display' will revert to the Idle Menu.

Press the Hands-free Key to finish programming.

Note: In the event of a power failure, you will need to reset the time and date.

Note: Changes to the system Time will only take place when any external calls in progress at that time have cleared.

Note: If the Network Provider supplies the Caller Number 'Display' service (CDS) the system time will be updated by the first incoming external call after 0200 hours PSTN lines only.

For Maintenance cover please call 01275 857910 for a quote.

www.perrettcommunications.com